

Fig. 1

80

Create user _____

Input new user

82

Type _____

Name _____

84

Select user model

86

Type _____

Name _____

86

Create

90

Fig. 3

The image shows a graphical user interface for managing user settings. It features three tabs at the top: "General" (selected), "User rights", and "User profile". Below the tabs are three main sections:

- Password:** A text input field containing asterisks, with a label "Password" to its left.
- Password confirmation:** A text input field containing asterisks, with a label "Password confirmation" to its left.
- Authorization level:** A horizontal slider control. The slider has a range from 0 to 5, with tick marks at each integer. A small square handle is positioned at the value 2. The label "Authorization level" is to the left of the slider.

Reference numerals are used to identify specific elements: 30 points to the main window frame, 32 to the "General" tab, 34 to the "User rights" tab, 36 to the "User profile" tab, 38 to the Password field, 100 to the Password confirmation field, and 102 to the Authorization level slider.

Fig. 4

32 34 36 30

General User rights User profile

Menus

☒ Are new menus visible?

☒ Print image

☐ ☒ Setup

☐ ☒ Change functions

☐ ☒ Counter

☒ Printer status

☐ Agent versions

☒ Operator Trace

☐ ☒ Channels

☐ ☒ Emulations

☒ General

☐ PCL Mode

☐ I-Mode

Elements

☒ Are new elements read-only?

☒ Color check-ID above

☒ Color check-ID below

☒ Version selection

☒ Variable paper length

☒ NPRO length

☒ Postprocessing present

☒ Test print pages

104 106

Fig. 5




Fig. 6

110

Select user _____

User

112

Bar/bce
Developer
Guest
Operator
Service
testService

Log in 114

Log out 116

Fig. 7